


ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS



15 min



0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14

① x 2




HW-ST-02-022
(6 x 25)

② x 2



HW-ST-07-152
(8.5 x 17 x 3)

③ x 2



HW-ST-02-105
(6 x 40)

④ x 2



HW-ST-03-004
(6 x 5)

⑤ x 2




HW-ST-07-060
(6.5 x 14 x 1)

⑥ x 1



HW-MM-18-026


⑦ x 1



HW-ST-18-009
(10 x 76)


Ⓐ x 1

HW-AL-26-025





Ⓑ x 1



SU-TB-LF-1525




Ⓒ x 2

SU-TB-LF-1526





 ③ x 2 HW-ST-02-105 (6 x 40)	 ④ x 2 HW-ST-03-004 (6 x 5)	 ⑤ x 2 HW-ST-03-004 (6 x 5)
--	---	---

